

2007 Fleetwood Niagara Tent Trailer

SET-UP and TAKE-DOWN Procedures

SET-UP

Setting up is the easy part. General Rule: **DO NOT FORCE ANYTHING**. If it doesn't move easily, find out why!

1. Release the 4 latches that hold the top down.
2. Raise the top all the way using the crank.
3. Pull out the beds first. Put up the bed supports (underneath).
4. Release the latches and pull out the slide-out.
5. On the inside, put up the bed roof supports (stored underneath each mattress). Put up the slide-out roof support (stored under the table).
6. On the outside, attach the elastics on each side of the beds, attaching the end hooks first.
7. Attach the Velcro all round the trailer in various places.
8. Install the door being very careful not to ding the cabinets. Attach the canvas to each side of the door.
9. Set up everything else as needed.

TAKE-DOWN

It is **VERY IMPORTANT** to take things down in the proper order to avoid damaging the trailer. It's easy to slide a bed in too soon and break or tear something!

1. Hang up the shower curtain and fold up the bathroom. Be sure not to forget to slip the protective covers over the ends of the bathroom door before stowing.
2. Undo and stow the bed and slide-out roof supports.
3. Undo and secure the outside bed support pipes.
4. **IMPORTANT:** Slide the side-out in **FIRST!** Undo the snaps and Velcro and slide it in being very careful not to pinch any of the canvas as it goes in. Secure the latches.
5. **IMPORTANT:** Pull the slide-out canvas out as shown in Photo 1. If you don't, there is a good chance the canvas will catch on the beds when they are pushed in and something will break or tear.



Photo 1

6. Push each bed in about a foot and then go to each side and fold the canvas toward the center of the bed as shown in Photo 2. This keeps the canvas from getting caught in the bed tracks as the bed is being pushed in.
7. Now, push each bed in as far as it will go. **DO NOT USE EXCESSIVE FORCE: IF IT CATCHES AND WON'T MOVE, STOP AND FIND OUT WHAT'S CAUSING THE PROBLEM.**
8. Fold the bed canvas in as shown in Photo 3.
9. After the beds are pushed in, push the slide-out canvas inward as shown in Photo 4.
10. Lower the top with the crank until it is about a foot from being closed.
11. Go around the trailer and fold the canvas in making the windows as flat as possible as shown in Photo 5.
12. Continue lowering the top until it is about 3" from being closed and check to see that there is no canvas hanging out.
13. Lower the top completely and secure all for latches. You may have to push down on the top to get each latch on its hook.
14. Once the latches are secured, give the crank a little turn until a "click" is heard. This takes the slack out of the lift mechanism for travelling.



Photo 2



Photo 3



Photo 4



Photo 5